QUICK INSTRUCTION GUIDE

1070 | CUTTER

Quick operating instructions • Keep this sheet for reference

PURPOSE	MODEL 1070
The WUKO 1070 Cutter is designed for clean cutting of sheet metal along straight and slightly curved lines.	Ergonomic handle and removable extension rod. Minimum cutting radius: 18 in.

BEFORE YOU START

- Inspect the cutter, handle, extension rod, and cutting wheels. Do not use damaged equipment.
- Wear safety glasses and appropriate cut-resistant gloves when handling sheet metal.
- Confirm the sheet material and thickness are within WUKO’s rated cutting capacity.

HOW TO USE

1. Position sheet metal on a stable, supported surface and mark the desired cutting line.
2. Attach the removable extension rod if additional reach or leverage is needed.
3. Position the cutter at the sheet edge and align the cutting wheels with the marked line.
4. Guide the cutter smoothly along the line using steady pressure. Maintain at least an 18 in radius on curved cuts.
5. When cutting directly from a coil, properly support and control the material as it feeds through the cutter.
6. Carefully remove the cut material; detach the extension rod if needed for storage or transportation.

IMPORTANT SAFETY NOTES

- Keep hands clear of cutting wheels, moving parts, and pinch points.
- Never force the cutter or cut material beyond the manufacturer’s rated capacity.
- Sheet metal and cut edges can be very sharp. Handle finished pieces carefully.

CARE AND STORAGE

After use, remove metal debris safely and store the cutter in a clean, dry location. Follow WUKO’s maintenance instructions.

SPECIFICATIONS

Minimum cutting radius: 18 in. Confirm material-specific cutting capacities with WUKO.
Extension rod: Removable. Attach and use according to the manufacturer’s instructions.

HELP AND REFERENCE

Manufacturer instructions: Consult the official WUKO 1070 manual. Customer support: rapidmaterials.com

IMPORTANT: This quick reference is a summary, not a replacement for the complete WUKO manufacturer instructions. Verify model-specific settings and cutting limits before use.