QUICK INSTRUCTION GUIDE

1250 | ROTARY SHEET METAL SHEARS

Quick operating instructions • Keep this sheet for reference

PURPOSE	MODEL 1250
The WUKO 1250 Rotary Sheet Metal Shears cut sheet metal using adjustable cutting wheels, an infeed support table, and a manual slider.	Supports sheets up to 50 in (1.25 m) wide. Adjustable cutting stop.

BEFORE YOU START

- Inspect the shears, slider, and cutting wheels before use. Do not use damaged equipment.
- Wear safety glasses and appropriate cut-resistant gloves when handling sheet metal.
- Confirm the sheet material and thickness are within WUKO’s rated cutting capacity.

HOW TO USE

1. Position sheet metal on the stainless steel infeed support table and align the cut line with the wheels.
2. Adjust the cutting stop to the desired measurement for consistent, repeatable cuts.
3. Verify that material thickness is within the rated capacity and that the sheet is properly supported.
4. Unfold the cutting slider handle and move the cutting mechanism smoothly along the sheet using steady pressure.
5. Carefully remove the cut metal pieces and return the cutting slider to its starting position.
6. Fold the cutting handle away when finished for storage or transportation.

IMPORTANT SAFETY NOTES

- Keep hands clear of cutting wheels, moving parts, and pinch points.
- Never force the shears or cut materials beyond the manufacturer’s rated capacity.
- Sheet metal and cut edges can be very sharp. Handle finished pieces carefully.

CARE AND STORAGE

After use, remove metal debris safely and store the shears in a clean, dry location. Follow WUKO’s maintenance instructions.

SPECIFICATIONS

Cutting width: Up to 50 in (1.25 m). Confirm material-specific cutting capacities with WUKO.

Cutting stop and slider: Set and operate according to the manufacturer’s instructions.

HELP AND REFERENCE

Manufacturer instructions: Consult the official WUKO 1250 manual. Customer support: rapidmaterials.com

IMPORTANT: This quick reference is a summary, not a replacement for the complete WUKO manufacturer instructions. Verify model-specific settings and cutting limits before use.